


OPERATOR'S SAFETY AND SERVICE MANUAL



2000, 2018 AP2000+ & 3550

This manual covers the following serial numbers and higher for each model listed:

2000.....2064575.
2018.....2180100.
3550.....3551200.



VIBRATORY PLATES

MBW, Inc.
250 Hartford Rd • PO Box 440
Slinger, WI 53086-0440
Phone: (262) 644-5234
Fax: (262) 644-5169
Email: mbw@mbw.com
Website: www.mbw.com

MBW (UK) Ltd.
Units 2 & 3 Cochrane Street
Bolton BL3 6BN, England
Phone: 01204 387784
Fax: 01204 387797

MBW FRANCE S.A.R.L.
Phone: +33 (0) 3 44 07 15 96

L18702/ 6.15.X
©MBW, Inc. 2015
Printed in the USA

TABLE OF CONTENTS

Safety Information	1
Introduction	1
Safety Precautions	1
Safety Decals	1
Specifications	3
Operation	5
Introduction	5
Before Starting & Operating	5
Starting Engine	5
Operating	5
Stopping Engine	5
Lifting/Transporting	5
Maintenance	6
Maintenance Schedule	6
Fluid Levels	6
Engine Maintenance	6
Engine Speed	6
Cleaning Plate	6
Belt Adjustment	6
Service	9
Torque Chart	9
Service Tools	9
Exciter Removal	9
(2000) Exciter Disassembly	9
(2000) Exciter Assembly	10
(3550) Exciter Disassembly	10
(3550) Exciter Assembly	10
Exciter installation	11
Parts Replacement Cycles and Tolerances	11
Replacement Parts	13
2000 & 2018 EXCITER ASSEMBLY	14
3550 Exciter Assembly	16
ENGINE ASSEMBLY 2000/2018	18
ENGINE ASSEMBLY 3550	20
ROLLCAGE ASSEMBLY	22
2018 ASSEMBLY	24
Warranty	26



WARNING



CALIFORNIA PROPOSITION 65 WARNING

Engine exhaust and some of its constituents are known in the state of California to cause cancer, birth defects, and other reproductive harm.

SAFETY INFORMATION

Introduction



This Safety Alert Symbol is used to call attention to items or operations which may be dangerous to those operating or working with this equipment. The symbol can be found throughout this manual and on the unit. Please read these warnings and cautions, along with all decals, carefully before attempting to operate the unit. Make sure every individual who operates or works with this equipment is familiar with all safety precautions.



WARNING



GENERAL WARNING. Indicates information important to the proper operation of the equipment. Failure to observe may result in damage to the equipment and/or severe bodily injury or death.



CAUTION



GENERAL CAUTION. Indicates information important to the proper operation of the equipment. Failure to observe may result in damage to the equipment.

Safety Precautions



LETHAL EXHAUST GAS: An internal combustion engine discharges carbon monoxide, a poisonous, odorless, invisible gas. Death or serious illness may result if inhaled. Operate only in an area with proper ventilation. **NEVER OPERATE IN A CONFINED AREA!**



DANGEROUS FUELS: Use extreme caution when storing, handling and using fuels, as they are highly volatile and explosive in vapor state. Do not add fuel while engine is running. Stop and cool the engine before adding fuel. **DO NOT SMOKE!**



SAFETY GUARDS: It is the owner's responsibility to ensure that all guards and shields are in place and in working order.



IGNITION SYSTEMS: Breakerless, magneto, and battery ignition systems can cause severe electrical shocks. Avoid contacting these units or their wiring.



SAFE DRESS: Do not wear loose clothing, rings, wristwatches, etc. near machinery.



NOISE PROTECTION: Wear OSHA specified hearing protection devices.



EYE PROTECTION: Wear OSHA specified eye shields, safety glasses, and sweat bands.



FOOT PROTECTION: Wear OSHA specified steel-tipped safety shoes.



HEAD PROTECTION: Wear OSHA specified safety helmets.



DUST PROTECTION: Wear OSHA specified dust mask or respirator.



OPERATOR: Keep children and bystanders off and away from the equipment.

REFERENCES: For details on safety rules and regulations in the United States, contact your local Occupational Safety and Health Administration (OSHA) office. Equipment operated in other countries must be operated and serviced in accordance and compliance with any and all safety requirements of that country. The publication of these safety precautions is done for your information. MBW does not by the publication of these precautions, imply or in any way represent that these are the sum of all dangers present near MBW equipment. If you are operating MBW equipment, it is your responsibility to insure that such operation is in full accordance with all applicable safety requirements and codes. All requirements of the United States Federal Occupational Safety and Health Administration Act must be met when operated in areas that are under the jurisdiction of that United States Department.

Safety Decals

Carefully read and follow all safety decals. Keep them in good condition. If decals become damaged, replace as required. If repainting the unit, replace all decals. Decals are available from authorized MBW distributors. Order the decal set listed on the following page(s).

AP2000


WWW.MBW.COM

20526 - 2000

20527 - 3550

ASPHALT WATER TANK


01066



16402



12500




PLATES OPERATING INSTRUCTIONS


1. Check engine oil.
2. Open fuel valve.
3. Choke engine. A warm engine may not need to be choked.
4. Open throttle part way.
5. Pull starter rope.
6. After starting: open choke, return throttle to idle position.
7. During operation, when excessive kickback is noticed, maximum compaction has been reached.
8. To stop: Return throttle to idle position, use engine stop switch, close fuel valve.

13482

13482



12573



Safety Decals (Decal Set #12100)

20019




18724 - 2000


19451 - 2018

18703 - 3550

SPECIFICATIONS



AP2000




AP2018

	AP2000	GP2000	AP2018	GP2018
CENTRIFUGAL FORCE	2475 lbf (1123 kg)	3250 lbf (1474 kg)	2475 lbf (1123 kg)	3250 lbf (1474 kg)
EXCITER (VPM)	4400	5050	4400	5050
TRAVEL SPEED	90 ft/min(28 m/min)	120 ft/min(36 m/min)	90 ft/min(28 m/min)	120 ft/min(36 m/min)
COMPACTION DEPTH	12 in (30 cm)	14 in (36 cm)	12 in (30 cm)	14 in (36 cm)
WIDTH x LENGTH x HEIGHT	20 x 22 x 21 in (51 x 56 x 53 cm)	20 x 22 x 21 in (51 x 56 x 53 cm)	20 x 22 x 18 in (51 x 56 x 46 cm)	20 x 22 x 18 in (51 x 56 x 46 cm)
OPERATING WEIGHT (HONDA)	168 lbs (76 kg) no water 193 lbs (88 kg) full water	165 lbs (75 kg)	168 lbs (76 kg) no water 178 lbs (81 kg) full water	163 lbs (74 kg)
ENGINE SPEED	3400 (RPM)	3400 (RPM)	3400 (RPM)	3400 (RPM)
WATER TANK CAPACITY	3 gal (11.3 l)		1 gal (4)	
NOISE LEVEL	84 - 94 dBA	84 - 94 dBA	84 - 94 dBA	84 - 94 dBA
ENGINE OPTIONS	HONDA GX160 (163 cm) ³ ROBIN EX13 (126 cm) ³ ROBIN EX17 (169 cm) ³ BRIGGS 550 (127 cm) ³			

Specifications subject to change without notice.

- No universal method or formula has been accepted for determining "Compaction Force". All manufacturers employ their own method or formula.

SPECIFICATIONS



AP3550

	AP3550	GP3550
CENTRIFUGAL FORCE	3550 lbf (1610 kg)	3550 lbf (1610 kg)
EXCITER (VPM)	4400	4400
TRAVEL SPEED	110 ft/min(34 m/min)	110 ft/min(34 m/min)
COMPACTION DEPTH	18 in (46 cm)	18 in (46 cm)
WIDTH x LENGTH x HEIGHT	21 x 22 x 22.2 in (53 x 56 x 56.3 cm)	21 x 22 x 22.2 in (53 x 56 x 56.3 cm)
OPERATING WEIGHT (HONDA)	229 lbs (104 kg) no water 254 lbs (115 kg) full water	226 lbs (103 kg)
ENGINE SPEED	3400 (RPM)	3400 (RPM)
WATER TANK CAPACITY	3 gal (11.3 l)	
NOISE LEVEL	84 - 94 dBA	84 - 94 dBA
ENGINE OPTIONS	HONDA GX160 (163 cc) ³ ROBIN EX13 (126 cc) ³ ROBIN EX17 (169 cc) ³	

Specifications subject to change without notice.

- No universal method or formula has been accepted for determining "Compaction Force". All manufacturers employ their own method or formula.

OPERATION

Introduction

MBW equipment is intended for use in very severe applications. They are powered by four cycle engines and are available in different sizes and a selection of engines.

This parts manual contains only standard parts. Variations of these parts as well as other special parts are not included. Contact your local MBW distributor for assistance in identifying parts not included in this manual.

Before Starting & Operating

- **HANDLE INSTALLATION** - Refer to ROLL CAGE ASSEMBLY, page 22. Install handle by removing handle attachment nuts. Reinstall handle attachment nut through the handle bushings from the inside in. Make sure nylon bushings inside the handle stay in place.
- **REMEMBER!** It is the owner's responsibility to communicate information on the safe use and proper operation of this unit to the operators.
- Review ALL of the Safety Precautions listed on page 1 of this manual.
- Familiarize yourself with the operation of the machine and confirm that all controls function properly.
- Know how to STOP the machine in case of an emergency.
- Make sure hands, feet, and clothing are at a safe distance from any moving parts.
- **OIL LEVEL** - Check the oil level in the engine. For more information see "Lubrication" under the respective engine's "Owners Manual" or the Maintenance section of this manual.
- **AIR CLEANER** - Check to ensure element is in good condition and properly installed.
- **FUEL SUPPLY** - The engines on MBW equipment require an automotive grade of clean, fresh, unleaded gasoline.
- **FUEL FILTER** - If clogged or damaged, replace.

Starting Engine

1. Open fuel valve.
2. Turn engine switch to "ON".
3. Set throttle to idle.
4. Choke engine if necessary (you may not need to choke a warm engine).

5. Pull starter rope repeatedly until engine starts.
6. Move choke lever to open position.
7. Allow engine to warm up for one or two minutes.

Operating


1. Open throttle fully.
2. Compactor will begin vibrating and moving in a forward direction.
3. Maximum compaction of soil has been reached when excessive kickback is noticed in the compactor. The number of passes needed to reach compaction level desired will depend on soil type and moisture.
4. When using the compactor on asphalt use the water sprinkling system to keep the plate bottom from adhering to the hot asphalt.

Stopping Engine

1. Move throttle to idle position.
2. Let engine idle for one or two minutes.
3. Turn switch on engine to "STOP" position.
4. Turn off fuel valve.

Lifting/Transporting

1. The unit can be lifted by the handles on the sides of the unit or by the roll cage.
2. The unit must be transported in the upright position. DO NOT lay machine on its side or top.
3. Secure or tie down unit using the lift handles or roll cage.



WARNING



Always stop the engine before:

Adding fuel.

Leaving the equipment unattended for any amount of time.

Before making any repairs or adjustments to the machine.

MAINTENANCE



WARNING



Always exercise the stopping procedure before servicing or lubricating the unit.

After servicing the unit, replace and fasten all guards, shields, and covers to their original positions before resuming operation.



CAUTION



Always verify fluid levels and check for leaks after changing fluids.

Do not drain oil onto ground, into open streams, or down sewage drains.

Maintenance Schedule

SYSTEM	MAINTENANCE	EACH USE	EVERY 50 HOURS	EVERY 250 HOURS	YEARLY
Engine	Refer to engine operator/owner manual	X			
Exciter	Check oil level		X		
	Check for oil leaks	X			
	Change oil			X	X
	Tighten Bolts ¹		X		X
Hardware	Check and tighten as needed ¹		X		X
Shockmounts	Check for cracks or tears		X		X

1. Check all hardware after the first 5 hours of use, then follow the maintenance schedule.

Fluid Levels

SYSTEM	FLUID VOLUME	RECOMMENDED OIL
Exciter	6 oz (2000 Plate) 8 oz. (3550 Plate)	MBW Ground Pounder® Exciter Oil ¹
Engine	Refer to engine operator/owner manual	

1. MBW #01058---- 6-Pack (8 oz. bottles)
MBW #17320---- 1 Quart (32 oz.)
MBW #20186-----1 Bottle (8 oz.)

Engine Maintenance

Refer to the engine Owner's Manual for maintenance intervals and procedures.

4. The engine idle speed must not exceed 1800 rpm. If the idle speed is greater than 1800 RPM the clutch may not disengage.

Engine Speed

1. Engine speed is factory set according to the speeds listed in the Specifications section of this manual. Do not tamper with the governor setting. The governor establishes safe operating limits which must not be exceeded.
2. Refer to the engine Owner's Manual for procedure on setting operating and idle speed.
3. The engine operating speed should be set to 3400 RPM.

Cleaning Plate

Remove any excess debris which may get into the housing of the unit.

Belt Adjustment

If any belt stretch develops follow these steps:
Reference engine assembly page.

1. Remove 4 flange bolts securing roll cage assembly to engine deck and remove roll cage assembly. See figure 1.

2. Apply moderate thumb pressure to belt about half way between pulleys. When properly adjusted the belt should deflect approximately 3/8" (9mm). If the belt is adjusted correctly reinstall belt guard and hardware.
3. To adjust belt tension loosen (do not remove) the (4) engine bolts.
4. Push engine towards the back of the plate. While holding pressure on the engine retighten the (4) engine bolts.
5. Recheck belt tension as described in step 2 and readjust if necessary until the proper tension is reached.
6. Reinstall roll cage assembly.

Checking Exciter Oil



WARNING



Exciter and oil is hot after machine has been running. Allow machine to cool before servicing unit.

1. Let exciter cool before checking oil.
2. Place plate on a level surface.
3. Remove roll cage assembly by removing (4) flange screws securing roll cage to engine deck. If machine





FIGURE 1


- is equipped with water tank disconnect hose from spray bar on front of plate. Now entire roll cage assembly, including roll cage, handle, water tank and belt guard, can be removed (see Figure 1).
4. Clean all dirt and debris from exciter to prevent contamination of exciter oil.
5. Remove pipe plug from top of exciter housing.
6. Rotate exciter shaft so a metal dip stick can be inserted into exciter (see Figure 2).
7. Place a clean metal rod through the oil fill hole as shown in figure 2.
8. Exciter should have approximately 3/4" (2000 plate) 7/8 to 1" (3550 plate) oil.
9. If oil need to be added, refer to Fluid Levels page of this section for type of oil to be used. DO NOT OVERFILL, over filling can cause excessive heat in exciter.
10. Apply pipe sealant to pipe plug and reinstall into top of exciter housing.
11. Reinstall roll cage assembly and re-attach hose to spray bar.

FIGURE 2

2000 PLATE



3550 PLATE



Changing Exciter Oil




WARNING

Exciter and oil is hot after machine has been running. Allow machine to cool before servicing unit.

1. Let exciter cool before changing oil.
2. Remove roll cage assembly by removing (4) flange screws securing roll cage to engine deck. If machine is equipped with water tank disconnect hose from spray bar on front of plate. Now entire roll cage assembly, including roll cage, handle, water tank and belt guard, can be removed (see Figure 1).

3. Remove 1/2" hex head cap screws and lock washers from side of bottom plate. Remove belt and engine deck assembly. Refer to figure 3
4. Clean all dirt and debris from exciter to prevent contamination of exciter oil.
5. Remove pipe plug from top of exciter housing. Tilt plate housing upside down to drain oil from housing.
6. (Optional 3550 Only) Remove oil drain screw and brass washer from exciter rear cover. Tilt bottom plate housing on it's side to drain oil from housing. After draining oil, return bottom plate housing to the upright position and replace oil drain screw and brass washer.
7. Return plate housing to the upright position.
8. Fill exciter with MBW Ground Pounder® exciter oil to level specified in the Fluid Levels section of this manual.
9. Apply pipe sealant to pipe plug and reinstall into top of exciter housing.
10. Reinstall engine deck assembly, belt and roll cage assembly. If equipped with water tank reattach hose to spray bar.

FIGURE 3



SERVICE

Assembly and disassembly should be performed by a service technician who has been factory trained on MBW equipment. The unit should be clean and free of debris. Pressure washing before disassembly is recommended.

- Prior to assembly, wash all parts in a suitable cleaner or solvent.
- Check moving parts for wear and failure. Refer to the Replacement section in this manual for tolerance and replacement cycles.
- All shafts and housings should be oiled prior to pressing bearings. Also, ensure that the bearings are pressed square and are seated properly.
- All bearings should be replaced when rebuilding any exciter or gearbox.
- All gaskets and seals should be replaced after any disassembly.

Torque Chart

SIZE	GRADE 2	GRADE 5	GRADE 8
1/4-20	49 in-lbs	76 in-lbs	9 ft-lbs
1/4-28	56 in-lbs	87 in-lbs	10 ft-lbs
5/16-18	8 ft-lbs	13 ft-lbs	18 ft-lbs
5/16-24	9 ft-lbs	14 ft-lbs	20 ft-lbs
3/8-16	15 ft-lbs	23 ft-lbs	33 ft-lbs
3/8-24	17 ft-lbs	26 ft-lbs	37 ft-lbs
7/16-14	24 ft-lbs	37 ft-lbs	52 ft-lbs
7/16-20	27 ft-lbs	41 ft-lbs	58 ft-lbs
1/2-13	37 ft-lbs	57 ft-lbs	80 ft-lbs
1/2-20	41 ft-lbs	64 ft-lbs	90 ft-lbs
9/16-12	53 ft-lbs	82 ft-lbs	115 ft-lbs
5/8-11	73 ft-lbs	112 ft-lbs	159 ft-lbs
5/8-18	83 ft-lbs	112 ft-lbs	180 ft-lbs
3/4-16	144 ft-lbs	200 ft-lbs	315 ft-lbs
1-8	188 ft-lbs	483 ft-lbs	682 ft-lbs
1-14	210 ft-lbs	541 ft-lbs	764 ft-lbs
1-1/2-6	652 ft-lbs	1462 ft-lbs	2371 ft-lbs
M 6	3 ft-lbs	4 ft-lbs	7 ft-lbs
M 8	6 ft-lbs	10 ft-lbs	18 ft-lbs
M 10	10 ft-lbs	20 ft-lbs	30 ft-lbs

CONVERSIONS

in-lbs x 0.083 = ft-lbs
ft-lbs x 12 = in-lbs
ft-lbs x 0.1383 = kg·m
ft-lbs x 1.3558 = N·m

Service Tools

Part No.	Description
17320	Ground Pounder® Exciter Oil
016129	Rubber Test Mat
12100	Decal Set

Exciter Removal

1. Remove roll cage assembly, engine deck assembly and belt. Refer to Changing Exciter Oil, page 7.
2. Remove 4 5/8-11 exciter bolts, washers, lock washers and nuts. If unit has exciter shims (7) make note of location to assure proper placement during reassembling.
3. Clean exciter and drain oil as described in Changing Exciter Oil section of this manual before proceeding with disassembly.

(2000) Exciter Disassembly

Refer to 2000 & 2018 EXCITER ASSEMBLY, page 14. for exciter disassembly.

1. Remove flange screw (23) and washer (8) securing the pulley (19) to the exciter shaft (20).
2. Slide pulley off of exciter shaft. be sure not to lose shaft key (17).
3. Remove 6 flange screws (23) from rear cover plate (2) and remove cover, opposite of pulley end.
4. Support exciter assembly on outside diameter of exciter housing (1) and press exciter shaft out of housing.
5. Remove 6 flange screws (22) from front cover plate (18) and remove front cover.

Note: If bearings have failed and need to be replaced then proceed with bearing removal steps. If bearings do not need replacing skip to step #9.

6. Support exciter housing (1) and press out front bearing (4).
7. Remove front bearing (4) inner race from exciter shaft by supporting O.D. of race and pressing exciter shaft thru.
8. Remove snap ring (6) and press rear bearing (5) off of shaft (20).
9. When reassembling always replace, oil seal (13) and front & rear cover gaskets (10 & 11).

(2000) Exciter Assembly

Refer to 2000 & 2018 EXCITER ASSEMBLY, page 14. for exciter disassembly.

1. Prior to assembly, clean all parts in a suitable solvent or cleaning solution. When a complete disassembly is done it is recommended that all seals, gaskets and bearings are replaced.

Note: If replacing bearings proceed to step #2, if not replacing bearings skip to step #6.

2. Press front bearing (4) inner race onto exciter shaft, pulley end.
3. Press front bearing (4) into exciter housing (1).
4. Press rear bearing (5) onto exciter shaft, opposite pulley end, use care to press on I.D. of bearing only.
5. Install snap ring (6) onto exciter shaft.
6. Press exciter shaft assembly into exciter housing (1). Use care to properly support O.D. of housing and guide shaft into bearing already in housing.
7. Press oil seal (13) into front cover (18), Seal to be press in until bottoming out on inside flange of front cover.
8. Install new gasket (10), front cover (18) and 6 flange screws (22). Torque flange screws to 13 ft.-lbs.
9. Install new gasket (11), rear cover (2) and 6 flange screws (23). Torque flange screws to 13 ft.-lbs.
10. Grease oil lip seal (13) and exciter shaft. Install key (17) on exciter shaft and slide pulley (19) onto shaft.
11. Install washer (8) and flange screw (23), torque flange screw to 13 ft.-lbs.
12. Fill exciter with MBW Ground Pounder® exciter oil to level specified in the Fluid Levels section of this manual.

(3550) Exciter Disassembly

Refer to 3550 Exciter Assembly, page 16. for exciter disassembly.

1. Remove flange screw (26) and washer (14) securing the pulley (2) to the exciter shaft (19).
2. Slide pulley off of exciter shaft. be sure not to lose shaft key (15).

Note: To aid in removal of rear cover you will need two 5/16-18 bolts, minimum grade 5.

3. Remove 6 flange screws (26) from rear cover plate (4). To press rear cover (4) off of housing, thread two 5/16-18 grade 5 bolts into thread holes on cover. Turn bolts in with wrench or ratchet to press cover out. When pressing cover off try to keep even pressure on both side to ensure cover comes out straight.

4. Support exciter assembly on outside diameter of exciter housing (1) and press exciter shaft out of housing.
5. Remove 6 flange screws (25) from front cover plate (3) and remove front cover.

Note: If bearings have failed and need to be replaced then proceed with bearing removal step 6. If bearings do not need replacing skip to step #9.

6. Support exciter housing (1) and press out front bearing (12) from inside out.
7. Remove retainer plate (6) by removing 2 cap screws (24).
8. Remove snap ring (8).
9. Remove bearing (11) from rear cover (4) with 1/4" punch. Tap the bearing out thru the holes for caps screws (24). Be sure to alternate between holes to avoid cocking the bearing.
10. Remove snap ring (9).
11. Remove bearing (11) inner race from exciter shaft by supporting O.D. of race and pressing exciter shaft thru.
12. When reassembling always replace sealing washer (5), oil seal (10) and front & rear cover gaskets (17 & 18).

(3550) Exciter Assembly


Refer to 3550 Exciter Assembly, page 16. for exciter assembly.

1. Prior to assembly, clean all parts in a suitable solvent or cleaning solution. When a complete disassembly is done it is recommended that all seals, gaskets and bearings are replaced.

Note: If replacing bearings proceed to step #2, if not replacing bearings skip to step #6.

2. Press front bearing (12) into exciter housing (1).
3. Press bearing (11) inner race onto exciter shaft (19).
4. Install snap ring (9) onto exciter shaft.
5. Support I.D. and O.D. of bearing (12) and press exciter shaft into bearing.
6. Check felt filter (13) to be sure it is not blocked or deteriorating, Replace if damaged.

FIGURE 4



7. Check and set end of spiro pin (23) to be 11/16" from inside of rear cover (4). **See Figure 4.**
8. Press bearing (11) into rear cover (4) and install snap ring (8) and gasket (18).

Note: To aid in assembly of rear cover you will need three, 5/16-18 x 2-1/2 minimum length bolts, to aid in alignment of rear cover.

9. Apply oil to I.D. of exciter housing and O.D. of rear cover.
10. Set rear cover (4) and new gasket (18) on exciter housing and install three alignment bolts into exciter housing.



CAUTION



Be sure that the inner bearing race is properly aligned to slide into the bearing. If proper alignment is not maintained the shaft may push the front bearing out of the housing.

11. Carefully press or tap the rear cover (4) down to seat on the exciter housing. Use care to keep cover straight when installing to prevent damaging housing or cover.
12. Remove the three alignment bolts and install six flange screws (26) securing the rear cover. Torque flange screws to 13 ft.-lbs.
13. Use medium strength thread lock when installing retainer plate (6) with 2 cap screws (24).
14. Install oil drain cap screw (24) and brass washer (27).
15. Press oil seal (10) into front cover (3). Seal to be press in until flush with front cover.
16. Install sealing washer (5).

17. Install new gasket (17), front cover (3) and 6 flange screws (25). Torque flange screws to 13 ft.-lbs.
18. Install new gasket (18), rear cover (6) and 6 flange screws (25). Torque flange screws to 13 ft.-lbs.
19. Grease oil lip seal (10) and exciter shaft. Install key (15) on exciter shaft and slide pulley (2) onto shaft.
20. Install washer (14) and flange screw (26), torque flange screw to 13 ft.-lbs.
21. Fill exciter with MBW Ground Pounder® exciter oil to level specified in the Fluid Levels section of this manual.

Exciter installation

Refer to exciter assembly pages for each unit.

1. Clean exciter mounting bars on bottom plate. If unit was equipped with exciter shims (3) replace to original position and set exciter assembly in place on mounting bars.
2. Check to make sure exciter sits flat on mounting bars, if not shim (3) as needed.
3. Install 4 5/8-11 exciter bolts, washers, lock washers, and 5/8-11 nuts. Torque exciter bolts to 150 ft.-lbs.
4. Reinstall engine deck, belt and roll cage assembly. If equipped with water tank reattach hose to spray bar. Adjust belt as described in Belt Adjustment section of this manual.

Parts Replacement Cycles and Tolerances

Bearings	Replace anytime a bearing is rough, binding, discolored or removed from housing or shaft.
Clutch	Replace clutch if it does not disengage below 1800 rpm.
Engine Components	Refer to your engine manufacturer's Owner's Manual.
Hardware	Replace any worn or damaged hardware as needed. Replacement hardware should be grade 5 and zinc plated unless otherwise specified.
Safety Decals	Replace if they become damaged or illegible.
Seals & Gaskets	Replace if a leak is detected and at every overhaul or tear down.
V-Belts	Replace if cracked, torn, or stretched to the point the belt won't tension properly.
Exciter Oil	Replace once every season or every 250 hours. Use 6 oz. (2000 plate), 8 oz. (3550 plate) Ground Pounder® exciter oil.

This page intentionally left blank.

REPLACEMENT PARTS


The warranty is stated in this book on page 14. Failure to return the Warranty Registration Card renders the warranty null and void.

MBW has established a network of reputable distributors/dealers with trained mechanics and full facilities for maintenance and rebuilding, and to carry an adequate parts stock in all areas of the country. Their sales engineers are available for professional consultation. If you cannot locate an MBW distributor in your area, contact MBW or one of our Sales Branches listed below.

When ordering replacement parts, be sure to have the following information available:

- Model and Serial Number of machine when ordering MBW parts
- Model and Serial Number of engine when ordering engine parts
- Part Number, Description, and Quantity
- Company Name, Address, Zip Code, and Purchase Order Number
- Preferred method of shipping

REMEMBER - You own the best! If repairs are needed, use only MBW parts purchased from authorized MBW distributors.



The unit's serial number can be found in the following locations:

- The model/serial number decal is located on the deck behind the engine.
- The serial number is stamped on the engine deck in the back left corner, top of exciter housing and on bottom plate exciter mounting bar.

Write Model Number here


Write Serial Number here

Contact Information

MBW, Inc.
250 Hartford Rd • PO Box 440
Slinger, WI 53086-0440
Phone: (262) 644-5234
Fax: (262) 644-5169
Email: mbw@mbw.com
Website: www.mbw.com


MBW (UK) Ltd.
Units 2 & 3 Cochrane Street
Bolton BL3 6BN, England
Phone: 01204 387784
Fax: 01204 387797

MBW FRANCE S.A.R.L.
Phone: +33 (0) 3 44 07 15 96




2000 & 2018 EXCITER ASSEMBLY

ITEM	PART NO.	DESCRIPTION	QTY
1.	00201	EXCITER HOUSING	1
2.	00206	REAR COVER	1
3.	00259	SHIM, EXCITER (AS REQUIRED)	
4.	01004	CYLINDRICAL ROLLER BEARING	1
5.	01070	BALL BEARING	1
6.	01071	RETAINING RING, EXTERNAL	1
7.	01072	FILTER, FELT	1
8.	01099	WASHER	1
9.	01191	RETAINING RING, INTERNAL	1
10.	06096	GASKET	1
11.	06097	GASKET	1
12.	13451	WASHER, 5/8, A325, STRUCTURAL	4
13.	17179	OIL SEAL	1
	01002	OIL SEAL, <u>SERIAL NO. 2064574 & LOWER</u>	
14.	18696	HHCS, 5/8-11 X 5-3/4, GRADE 8	4
15.	18697	BASEPLATE	1
16.	18701	HEX NUT, 5/8-11, GRADE 8	4
17.	19135	KEY, 1/4" SQ. X 3/4 SQUARE ENDS	1
18.	01283	KEY, 1/4" SQ. X 1-1/4 ROUND ENDS, <u>SERIAL NO. 2064574 & LOWER</u>	
	19628	FRONT COVER	1
19.	00005	FRONT COVER, <u>SERIAL NO. 2064574 & LOWER</u>	
	19629	PULLEY, 4-3/8 DIA x 1.0 I.D., AP2000 (ASPHALT VERSION)	1
	19630	PULLEY, 3-7/8 DIA x 1.0 I.D., GP2000 (SOIL VERSION & AP2000+)	1
	00003	PULLEY, 4-3/8 DIA x 1-1/8 I.D., AP2000 (ASPHALT PLATE) <u>SER. NO. 2064574 & LOWER</u>	
20.	00348	PULLEY, 3-7/8 DIA x 1-1/8 I.D., GP2000 (SOIL & 2000+ PLATE) <u>SER. NO. 2064574 & LOWER</u>	
	19835	EXCITER SHAFT	1
21.	00202	EXCITER SHAFT, <u>SERIAL NO. 2064574 AND LOWER</u>	
	F0205SP	SPIROL PIN, 1/8 X 5/8 LG.	1
22.	F051806FWS	FLANGE LOCKING SCREW, 5/16-18 X 3/4 LG.	6
23.	F051808FWS	FLANGE LOCKING SCREW, 5/16-18 X 1 LG	7
24.	F0612SP	PIN, SPIROL	1
25.	F0618SPP	SOCKET PIPE PLUG, 3/8-18	3
26.	F10LW	LOCKWASHER, 5/8, ZP	4
	<u>SERVICE PARTS:</u>		
	00062	WASHER SEAL, PULLEY (NOT SHOWN) <u>SERIAL NO. 2064574 AND LOWER</u>	
	<u>REPLACEMENT KIT:</u>		
	19836	EXCITER ASSEMBLY (<u>DOES NOT INCLUDE ITEMS 8, 17, 19 & 23</u>)	
	19837	EXCITER ASM. ASPHALT (INCLUDES ITEMS 8, 17, 19 & 23) <u>SERIAL NO. 2064574 & BELOW</u>	
	19838	EXCITER ASM. SOIL (INCLUDES ITEMS 8, 17, 19 & 23) <u>SERIAL NO. 2064574 & BELOW</u>	
	18757	BOTTOM PLATE, AP/GP2000 (INCLUDES ITEMS: 3, 12, 14, 15, 16, 24, 25 & 26)	




3550 Exciter Assembly

ITEM	PART NO.	DESCRIPTION	QTY
1.	00001	EXCITER HOUSING	1
2.	00006	REAR COVER	1
3.	00066	RETAINER PLATE	1
4.	00259	SHIM EXCITER (AS REQUIRED)	
5.	01000	RETAINING RING, INTERNAL	1
6.	01001	RETAINING RING, EXTERNAL	1
7.	01004	CYLINDRICAL ROLLER BEARING	1
8.	01005	SPHERICAL ROLLER BEARING	1
9.	01072	FILTER, FELT	1
10.	01099	WASHER	1
11.	06096	GASKET	1
12.	06098	GASKET	1
13.	17179	OIL SEAL	1
	01002	OIL SEAL, <u>SERIAL NO. 3551199 & LOWER</u>	
14.	18577	BASE PLATE	1
15.	18700	HHCS, 5/8-11 X 6 GRADE 8	4
16.	18701	HEX NUT, 5/8-11, GRADE 8 ZP	4
17.	19135	KEY, 1/4" SQ. X 3/4 SQUARE ENDS	1
	01283	KEY, 1/4" SQ. X 1-1/4 ROUND ENDS, <u>SERIAL NO. 3551199 & LOWER</u>	
18.	19628	FRONT COVER	1
	00005	FRONT COVER, <u>SERIAL NO. 3551199 & LOWER</u>	
19.	19629	PULLEY, EXCITER 4-3/8 DIA x 1.0 I.D.	1
	00003	PULLEY, 4-3/8 DIA x 1-1/8 I.D., <u>SERIAL NO. 3551199 & LOWER</u>	
20.	19912	EXCITER SHAFT	1
	18692	EXCITER SHAFT, <u>SERIAL NO. 3551199 & LOWER</u>	
21.	F0205SP	SPIROL PIN, 1/8 X 5/8 LG.	1
22.	F051804HCS	HEX HEAD CAP SCREW, 5/16-18 X 1/2LG.	3
23.	F051806FWS	FLANGE LOCKING SCREW, 5/16-18 X 3/4 LG.	6
24.	F051808FWS	FLANGE LOCKING SCREW, 5/16-18 X 1 LG	7
25.	F05BFW	WASHER, BRASS, 5/16	1
26.	F0612SP	SPIROL PIN	1
27.	F0618SPP	SOCKET PIPE PLUG, 3/8-18	3
28.	F10LW	LOCKWASHER, 5/8	4
29.	F10PW	WASHER, 5/8	4
		<u>SERVICE PARTS:</u>	
	00062	WASHER SEAL, PULLEY (NOT SHOWN) <u>SERIAL NO. 2064574 & LOWER</u>	
		<u>REPLACEMENT KIT</u>	
	19913	EXCITER ASSEMBLY (COMPLETE)	
	18758	BOTTOM PLATE, AP/GP3550 (INCLUDES ITEMS:7. 19, 20, 21, 27, 28, 29 & 30)	




ENGINE ASSEMBLY 2000/2018


ITEM	PART NO.	DESCRIPTION	2000H	2000R	2000B	2018H	2018R	2018B
1.	00031	MOUNTING BAR, ENGINE	2	2	2	2	2	2
2.	00032	SHAFT KEY, 3/16" SQUARE x 1-5/8 LG.	1	1	1	1	1	1
3.	00048	HOOK BOLT, 5/16-18	1	1	1	1	1	1
4.	01011	SHOCK MOUNT	4	4	4	4	4	4
5.	01013	V-BELT A-30	1	1	1	1	1	1
6.	01099	WASHER	1	1	1	1	1	1
7.	01444 17210	ENGINE HONDA, GX160 ENGINE ROBIN, EX13	1	1	1	1	1	1
	17370 20382	ENGINE ROBIN, EX17 (OPTIONAL) ENGINE, BRIGGS, 550 SERIES (127 cc)		1	1		1	1
8.	07636	DEFLECTOR, EXHAUST, (HONDA)	1			1		
9.	19531	ENGINE DECK	1	1	1			
10.	19447 16105	ENGINE DECK CLUTCH, CENTRIFUGAL		1	1	1	1	1
11.	F0203HTB	SCREW, #8 x 3/8" LG. TYPE A, WASHER HEAD	2			2		
12.	F051814HCS	HHCS, 5/16-18 x 1-3/4 LG. GRADE 5	4	4	4	4	4	4
13.	F0518FN	NUT, FLANGE WHIZ-LOCK, 5/16-18, ZP	2	2	2	2	2	2
14.	F052408HCS	HHCS, 5/16-24 X 1 LG. ZP	1	1	1	1	1	1
15.	F05LW	LOCKWASHER, 5/16, ZP	4	4	4	4	4	4
16.	F05SW	WASHER, 5/16, ZP	4	4	4	4	4	4
17.	F06SW	WASHER, 3/8, ZP		4	4		4	4
18.	F081305HCS	HHCS, 1/2-13 x 5/8 LG. GRADE 5, ZP	4	4	4	4	4	4
19.	F081306HCS	HHCS, 1/2-13 x 3/4 LG. GRADE 5, ZP	4	4	4	4	4	4
20.	F08LW	LOCKWASHER, 1/2, ZP	4	4	4	4	4	4
21.	M12ETLW	LOCKWASHER, M12, EXTERNAL TOOTH	4	4	4	4	4	4
22.	M06C010BCS	BUTTON HEAD SCREW, M6 x 10mm	1			1		
		<u>KITS:</u>						
	20185	SERVICE KIT, HONDA 2000 PLATE, (4) #01011 SHOCK MOUNT						
		(4) #17170 SHOCK MOUNT						
		(1) #01013 V-BELT						
		(1) #19951 1-QUART OIL, 10W30 OIL						
		(1) #20186 oz. BOTTLE EXCITER OIL						
		(1) #Q17210ZE1822 AIR CLEANER ELEMENT						
		(1) #Q9807956846 SPARK PLUG						




ENGINE ASSEMBLY 3550

ITEM	PART NO.	DESCRIPTION	3550H	3550R
1.	00031	MOUNTING BAR, ENGINE	2	2
2.	00032	SHAFT KEY, 3/16" SQUARE x 1-5/8 LG.	1	1
3.	00048	HOOK BOLT, 5/16-18	1	1
4.	01011	SHOCK MOUNT	4	4
5.	07288	V-BELT A-32, (SERIAL NO 35500759 & BELOW)	1	1
	06931	V-BELT A-31, (SERIAL NO 35500760 & UP)	1	1
6.	01099	WASHER	1	1
7.	01444	ENGINE HONDA, GX160	1	
	17210	ENGINE ROBIN, EX13		1
	17370	ENGINE ROBIN, EX17 (OPTIONAL)		1
8.	07636	DEFLECTOR, EXHAUST, (HONDA)	1	
9.	19531	ENGINE DECK	1	1
10.	16105	CLUTCH, CENTRIFUGAL	1	1
11.	F0203HTB	SCREW, #8 x 3/8" LG. TYPE A, WASHER HEAD	2	
12.	F051814HCS	HHCS, 5/16-18 x 1-3/4 LG. GRADE 5	4	4
13.	F0518FN	NUT, FLANGE WHIZ-LOCK, 5/16-18, ZP	2	2
14.	F052408HCS	HHCS, 5/16-18 X 1 LG. ZP	1	1
15.	F05LW	LOCKWASHER, 5/16, ZP	4	4
16.	F05SW	WASHER, 5/16, ZP	4	4
17.	F06SW	WASHER, 3/8, ZP		4
18.	F081306HCS	HHCS, 1/2-13 x 3/4 LG. GRADE 5, ZP	4	4
19.	F081307HCS	HHCS, 1/2-13 x 7/8 LG. GRADE 5, ZP	4	4
20.	F08LW	LOCKWASHER, 1/2, ZP	4	4
21.	M12ETLW	LOCKWASHER, M12, EXTERNAL TOOTH	4	4
22.	M06C010BCS	BUTTON HEAD SCREW, M6 x 10mm	1	
		<u>KITS:</u>		
	20188	SERVICE KIT, HONDA 3550 PLATE, INCLUDES:		
		(4) #01011 SHOCK MOUNT		
		(4) #17170 SHOCK MOUNT		
		(1) #06931 V-BELT		
		(1) #19951 1-QUART OIL, 10W30 OIL		
		(1) #20186 oz. BOTTLE EXCITER OIL		
		(1) #Q17210ZE1822 AIR CLEANER ELEMENT		
		(1) #Q9807956846 SPARK PLUG		






WATER TANK CAPS



USE TANK CAP #19495



USE TANK CAP #00196

2018 ASSEMBLY

WARRANTY

WHAT DOES THIS WARRANTY COVER? MBW, Incorporated (MBW) warrants each New Machine against defects in material and workmanship for a period of twelve (12) months. "New Machine" means a machine shipped directly from MBW or authorized MBW dealer to the end user. This warranty commences on the first day the machine is sold, assigned to a rental fleet, or otherwise put to first use.

MBW warrants each Demonstration Machine against defects in material and workmanship for a period of six (6) months. "Demonstration Machine" means a machine used by MBW or its agents for promotional purposes. This warranty commences on the first day the machine is sold, assigned to a rental fleet, or otherwise put to first use.

This warranty covers the labor cost for replacement or repair of parts, components, or equipment on New Machines or Demonstration Machines, and MBW shall pay labor costs at MBW's prevailing rate to affect the warranted repair or replacement. MBW reserves the right to adjust labor claims on a claim-by-claim basis.

This warranty covers the shipping cost of replacement parts, components, or equipment via common ground carriers from MBW to an authorized MBW dealer. Air freight is considered only in cases where ground transportation is not practical.

MAY THIS WARRANTY BE TRANSFERRED? This warranty is non-transferable and only applies to the original end user of a new machine or demonstration machine.

WHAT DOES THIS WARRANTY NOT COVER?

1. This warranty does not cover any Used Equipment. "Used Equipment" means any MBW machine or equipment that is not a New Machine or a Demonstration Machine. All Used Equipment is sold **AS IS/WHERE IS WITH ALL FAULTS.**

2. This warranty does not cover any New Machine, Demonstration Machine, or their equipment, parts, or components altered or modified in any way without MBW's prior written consent. This warranty does not cover the use of parts not specifically approved by MBW for use on MBW products. This warranty does not cover misuse, neglect, shipping damage, accidents, acts of God, the operation of any New Machine or Demonstration Machine in any way other than recommended by MBW in accordance with its specifications, or any other circumstances beyond MBW's control. This warranty does not cover any New Machine or Demonstration Machine repaired by anyone other than MBW factory branches or authorized MBW distributors.

3. This warranty does not cover, and MBW affirmatively disclaims, liability for any damage or injury resulting directly or indirectly from design, materials, or operation of a New Machine or Demonstration Machine or any other MBW product. MBW's liability with respect to any breach of warranty shall be limited to the provisions of this document and in no event shall exceed an amount equal to the purchase price of the New Machine or Demonstration Machine purchased from MBW.

4. This warranty does not cover engines, motors, and other assemblies or components produced by other manufacturers and used on a New Machine or Demonstration Machine, as said engines, motors, and other assemblies or components may have warranties provided by the manufacturer thereof. This warranty does not apply to consumable items, such as v-belts, filters, trowel and screed blades, seals, shock mounts, batteries, and the like, all of which are sold **AS IS/WHERE IS WITH ALL FAULTS.**

5. This warranty does not cover the cost of transportation and other expenses which may be connected with warranty service but not specifically mentioned herein.

6. This warranty does not cover any updates to any New Machine, Demonstration Machine, or any other MBW product. MBW reserves the right to improve or make product changes without incurring any obligation to update, refit, or install the same on New Machines or Demonstration Machines previously sold.

WHAT MUST YOU DO TO OBTAIN WARRANTY COVERAGE? Each New Machine or Demonstration Machine is accompanied by a Warranty Registration Card. You must sign, date, and return the Warranty Registration Card to the place of origin of the New Machine or Demonstration Machine, either to MBW, Inc. at P.O. Box 440, Slinger, Wisconsin 53086, MBW (UK), Ltd. at Units 2 & 3 Cochrane Street, Bolton BL3 6BN, United Kingdom or MBW FRANCE SARL at ZA D'Outreville, 5 Rue Jean Baptiste Neron, Bornel 60540 France, within ten (10) days after purchase, assignment to a rental fleet, or first use. This signed warranty card is the buyer's affirmation that he has read, understood, and accepted the warranty at the time of purchase. Failure to return the warranty card as specified herein renders the warranty null and void. In order to receive warranty coverage consideration, warranty claims must be submitted within thirty (30) days after the New Machine or Demonstration Machine fails. Warranty claims must be submitted to MBW, Inc., MBW (UK), Ltd. or MBW FRANCE SARL, and written authorization for the return of merchandise or parts under the warranty must be obtained before shipment to MBW.

WHAT WILL MBW DO? MBW's obligation under this warranty is limited to the replacement or repair of parts for a New Machine or Demonstration Machine at MBW factory branches or at authorized MBW distributors, and such replacement or repair is the exclusive remedy provided hereunder. Labor must be performed at an authorized MBW distributor. MBW reserves the right to inspect and render a final decision on each warranty case, and MBW's repair or replacement is solely within the discretion of MBW.

IT IS EXPRESSLY AGREED THAT THIS SHALL BE THE SOLE AND EXCLUSIVE REMEDY UNDER THIS WARRANTY. UNDER NO CIRCUMSTANCES SHALL MBW BE LIABLE FOR ANY COSTS, LOSS, EXPENSE, DAMAGES, SPECIAL DAMAGES, INCIDENTAL DAMAGES, OR PUNITIVE DAMAGES ARISING DIRECTLY OR INDIRECTLY FROM THE USE OF THE NEW MACHINE OR DEMONSTRATION MACHINE WHETHER BASED UPON WARRANTY, CONTRACT, NEGLIGENCE, STRICT LIABILITY, OR ANY OTHER LEGAL THEORY.

THE FOREGOING WARRANTY IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR USE, AND FITNESS FOR A PARTICULAR PURPOSE, AND ALL OTHER OBLIGATIONS OR LIABILITY ON MBW'S PART. MBW NEITHER ASSUMES NOR AUTHORIZES ANY OTHER PERSON TO ASSUME ON BEHALF OF MBW ANY OTHER LIABILITY OR WARRANTY IN CONNECTION WITH THE SALE OR SERVICE OF ANY NEW MACHINE, DEMONSTRATION MACHINE, OR ANY OTHER MBW PRODUCT.

EXTENDED RAMMER WARRANTY - MODELS R422, R442, R482 & R483.

This extended warranty commences on the last day of MBW's standard, one year, "limited warranty" and runs for an additional four years (48 months). This extended warranty is limited to part replacement and shipping costs of rammer **bellows and non-metallic slide bearings only.** This extended warranty does not cover labor, down time, or any other cost beyond that of component replacement and freight. This extended warranty is subject to all limitations set forth in MBW's "limited warranty", above.